

P&WERZOD

C550P6

1800

220~480

60

3-PH

0.8

122

24V

120

2

35

STACKABLE

ESP


480/600

PRP

440/550

V

GENERATOR MODEL Ð POWERZOD 17 Generator specificationsl Ħ 12 M kW/kVA Power (7) $(\underline{})$ Rated speed r.p.m. V Available voltages Emergency Standby Power (ESP): Applicable for supplying power to varying electrical load for the duration 50/60 HZ Frequency Hz of power interruption of a reliable utili ty source. Emergency Standby Power (ESP) is in accordance with ISO 8528. Fuel Stop power in accordance with ISO 3046, AS 2789, DIN 6271 and BS 5514. 3 Phase Prime Power (PRP): Applicable for supplying power to varying electrical load for unlimited hours. Prime Power (PRP) is in accordance with ISO 8528. Ten percent overload capabili ty is avai lable in accordance with ISO 3046, AS 2789, DIN (at a Power factor $\cos \phi$ 6271 and BS 5514. Continuous Power (COP): Applicable for supplying power continuously to a constant electrical load Fuel cons 100% L/H for unlimi ted hours. Continuous Power (COP) in accordance wi th ISO 8528, ISO 3046, AS 2789, DIN6271 and BS 5514. POWERZOO generators are CE certified and conform to the following Directives: VDC Starting power •EN 12100: 2010, EN ISO 8528-13: 2016, EN 60204-1: 2018, •EN 61000-6-2: 2019, 2006/42/CE Machinery safety •2014/35/EU Low voltage Recommended Ah •2014/30/EU Electromagnetic compatibility battery •Power according to ISO 8528 and ISO 3046 - + •Ambient reference conditions 1000 mbar, $25\,^\circ$ C, 30% relative humidity. Information based on standard specification equipment unless otherwise Number of batteries stated. Auxiliary voltage WATER-COOLED)) REQUENCY DIESEL FUEL SOUNDPROOF **Dimension and Weight**



	DIMENSION		OPEN TYPE	SILENT TYPE
· · · · · · · · · · · · · · · · · · ·	Length (L)	mm	3410	4906
	Width (W)	mm	1360	1600
	Height (H)	mm	2445	2390
Kg	Dry Weight	kg	3850	5895
	Fuel tank	L	850	850

A

SO 9001

POWERZOO has the right to modify any feature without prior notice. Weights and dimensions based on standard products. Illustrations may include optional equipment. Technical data described in this catalogue correspond to the available information at the moment of printing. The illustrations and images are indicative and may not coincide in their entirety with the product. Industrial design under patent.





Engine Specifications

ENGINE	Cummins®	ENGINE	Cummins®
Engine model	KTA19-G4	Total lubrication system capacity	50 L
Number of cylinders	6	Coolant capacity (with radiator)	66 L
Cylinder arrangement	Vertical in-line	Speed stability (%)	≤3%
Cycle	Four stroke	Start type	Electrical
Aspiration	Turbocharged, Aftercooled	Maximum exhaust temperature	504 °C
Bore × Stroke	159 × 159 mm	Exhaust gas flow	1862 L/S
Displacement	18.9 L	Maximum allowed back pressure	10 kPa
Compression ratio	14.5:1	Intake air flow	716 L/S
Prime power/Speed	507/1800 (kW/rpm)	Engine water flow	5 L/min
Standby power/Speed	563/1800 (kW/rpm)	Consumption @ 100% load ESP	136 L/H
Speed governor	Electronic	Consumption @ 100% load PRP	122 L/H
Cooling system (open type)	40°C tropical radiator	Consumption @ 75% load PRP	94 L/H
Cooling system (silent type)	50℃ tropical radiator	Consumption @ 50% load PRP	65 L/H



Features:

Diesel engine

- •4-stroke cycle
- •Water-cooled

•Dry air filter

- •Radiator with pusher fan
- •Moving parts protection
- •Radiator water level sensor
- •55 degree radiator (Option

•Jacket coolant heater (Optional) •Lube oil heater (Optional) •Engine filter heater (Optional) let line heater (Optional) duty air filter (Optional)

Alternator Specification

ALTERNATOR		ALTERNATOR	
Exciter type	Brushless, self-excited	Voltage regulation NL-FL	≤±1.0%
Power factor	0.8	Insulation grade	н
Voltage adjust range	≥5%	Protection grade	IP23



Options:

- •AREP/PMG/EBS
- •Air inlet filter (5% deration)
- •louver (5% deration)

•Space heater •Digital AVR

•Severe environmental impregnation

- •Stator sensor
- •PT100

- •Rotor sensor
- •Double bearing
- •Drip proof cover
- Terminal box IP44




E-mail: info@powerzoos.com Tel: +86 13358296663

	5
r (Optional)	•Fuel inl
ial)	•Heavy o



P\$WERZOD



Controller Functions

OPTIONAL CONFIGURATION	Stand-alone Basic	Stand-alone Advanced	Synchronization Basic	Synchronization Advanced
Voltage between phases	•	•	•	•
Voltage between neutral and phase	•	•	•	•
Current intensities	•	•	•	•
Frequency	•	•	•	•
Apparent power (kVA)	•	•	•	•
Active power (kW)	•	•	•	•
Reactive power (kVAr)	•	•	•	•
Power factor	•	•	•	•
Coolant temperature	•	•	•	•
Oil pressure	•	•	•	•
Battery voltage	•	•	•	•
R.P.M.	•	•	•	•
Battery charge alternator voltage	•	•	•	•
High water temperature by sensor	•	•	•	•
Low oil pressure by sensor	•	•	•	•
Unexpected shutdown	•	•	•	•
Fuel storage by sensor	•	•	•	•
Stop failure/Start failure	•	•	•	•
Overspeed/Underspeed	•	•	•	•

lacksquare Standard \hdotsquare Optional





PØWERZOD

mergency stop igh/Low frequency	•	•	•	•
igh/Low frequency	•	•		
	•		•	•
igh/Low voltage		•	•	•
hort-circuit	•	•	•	•
correct phase sequence	•	•	•	•
verse power	•	٠	•	•
verload	•	•	•	•
otal hour counter	•	•	•	•
ilowatt meter	•	•	•	•
tarts valid counters	•	•	•	•
laintenance	•	•	•	•
SB	•	•	•	•
oftware for PC	•	•	•	•
larm history	•	•	•	•
xternal start	•	•	•	•
tart inhibition	•	•	•	•
lains failure start	•	•	•	•
re-heating engine control	•	•	•	•
uel transfer control	•	•	•	•
ngine temperature control	•	•	•	•
rogrammable alarms	•	•	•	•
enset start function in test mode	•	•	•	•
rogrammable outputs	•	•	•	•
lultilingual	•	•	•	•
S485		•	•	•
lodbus IP		•	•	•
1939		•	•	•
ynchronization			•	•
lains synchronization				•
uel level (%)	0	0	0	0
ow water level	0	О	0	0
SM/GPRS modem	0	0	0	0
emote screen	0	0	0	0

• Standard O Optional



E-mail: info@powerzoos.com Tel: +86 13358296663