





Emergency Standby Power (ESP):

Applicable for supplying power to varying electrical load for the duration of power interruption of a reliable utili ty source. Emergency Standby Power (ESP) is in accordance with ISO 8528. Fuel Stop power in accordance with ISO 3046, AS 2789, DIN 6271 and BS 5514.

Prime Power (PRP):

Applicable for supplying power to varying electrical load for unlimited hours. Prime Power (PRP) is in accordance with ISO 8528. Ten percent overload capabili ty is available in accordance with ISO 3046, AS 2789, DIN 6271 and BS 5514.

Continuous Power (COP):

Applicable for supplying power continuously to a constant electrical load for unlimited hours. Continuous Power (COP) in accordance with ISO 8528, ISO 3046, AS 2789, DIN6271 and BS 5514.

POWERZOO generators are CE certified and conform to the following Directives:

- •EN 12100: 2010, EN ISO 8528-13: 2016, EN 60204-1: 2018,
- •EN 61000-6-2: 2019, 2006/42/CE Machinery safety
- $\bullet 2014/35/\text{EU}$ Low voltage
- •2014/30/EU Electromagnetic compatibility
- •Power according to ISO 8528 and ISO 3046
- Ambient reference conditions 1000 mbar, 25° C, 30% relative humidity.
 Information based on standard specification equipment unless otherwise stated.

GENERATOR MODEL			P80P5		
<u>(118)</u>	Generator specificationsl		PRP	ESP	
•	Power	kW/kVA	64/80	70/88	
(2)	Rated speed	r.p.m.	1500		
v	Available voltages	V	380~415		
50 60 HZ	Frequency	Hz	50		
3 PH	Phase		3-PH		
	Power factor	Cos Φ	0.8		
	Fuel cons 100%	L/H	18.7		
	Starting power	kVV	3		
ÁTŘ	Recommended battery	Ah	45		
_	Number of batteries		2 (PARALLELING)		
	Auxiliary voltage	VDC	12V		
















Dimension and Weight



	DIMENSION		OPEN TYPE	SILENT TYPE
☆点	Length (L)	mm	1900	2602
Ø.₩	Width (W)	mm	950	1100
	Height (H)	mm	1400	1525
Kg	Dry weight	kg	1150	1650
	Fuel tank	L	120	120

POWERZOO has the right to modify any feature without prior notice. Weights and dimensions based on standard products. Illustrations may include optional equipment. Technical data described in this catalogue correspond to the available information at the moment of printing. The illustrations and images are indicative and may not coincide in their entirety with the product. Industrial design under patent.









Engine Specifications

ENGINE	Perkins [®]	
Engine model	1104A-44TG2	
Number of cylinders	4	
Cylinder arrangement	Vertical in-line	
Cycle	Four stroke	
Aspiration	Turbocharged	
Bore × Stroke	105*127mm	
Displacement	4.4	
Compression ratio	17.25:1	
Prime power/Speed	73.4/1500 (kW/rpm)	
Standby power/Speed	80.7/1500 (kW/rpm)	
Speed governor	Mechnical	
Cooling system (open type)	40°C tropical radiator	
Cooling system (silent type)	$50^{\circ}\!$	

ENGINE	Perkins [®]
Total lubrication system capacity	8.0 L
Coolant capacity (with radiator)	13 L
Speed stability (%)	≤5%
Start type	Electrical
Maximum exhaust temperature	555°C
Exhaust gas flow	12.5 m³/min
Maximum allowed back pressure	10 kPa
Intake air flow	ТВА
Cooling air flow	ТВА
Consumption @ 100% load ESP	20.5 L/H
Consumption @ 100% load PRP	18.7 L/H
Consumption @ 75% load PRP	14.0 L/H
Consumption @ 50% load PRP	9.7 L/H



Features:

- •Diesel engine
- •4-stroke cycle
- •Water-cooled

- •Dry air filter
- •Radiator with pusher fan
- •Moving parts protection
- •Radiator water level sensor (Optional)
- •55 degree radiator (Optional)

- Jacket coolant heater (Optional)
- •Lube oil heater (Optional)
- •Engine filter heater (Optional)
- •Fuel inlet line heater (Optional)
- •Heavy duty air filter (Optional)



Alternator Specification

ALTERNATOR	
Exciter type	Brushless, self-excited
Power factor	0.8
Voltage adjust range	≥5%

ALTERNATOR	
Voltage regulation NL-FL	≤±1.0%
Insulation grade	Н
Protection grade	IP23



Options:

- •AREP/PMG/EBS
- •Air inlet filter (5% deration)
- •louver (5% deration)
- •Space heater
- •Digital AVR
- •Severe environmental impregnation
- •Stator sensor
- •PT100

- •Rotor sensor
- Double bearing
- •Drip proof cover
- •Terminal box IP44









Controller Brands







CamAp



DEF





Woodward



Controller Functions

OPTIONAL CONFIGURATION	Stand-alone Basic	Stand-alone Advanced	Synchronization Basic	Synchronization Advanced
Voltage between phases	•	•	•	•
Voltage between neutral and phase	•	•	•	•
Current intensities	•	•	•	•
Frequency	•	•	•	•
Apparent power (kVA)	•	•	•	•
Active power (kW)	•	•	•	•
Reactive power (kVAr)	•	•	•	•
Power factor	•	•	•	•
Coolant temperature	•	•	•	•
Oil pressure	•	•	•	•
Battery voltage	•	•	•	•
R.P.M.	•	•	•	•
Battery charge alternator voltage	•	•	•	•
High water temperature by sensor	•	•	•	•
Low oil pressure by sensor	•	•	•	•
Unexpected shutdown	•	•	•	•
Fuel storage by sensor	•	•	•	•
Stop failure/Start failure	•	•	•	•
Overspeed/Underspeed	•	•	•	•

● Standard ○ Optional







OPTIONAL CONFIGURATION	Stand-alone Basic	Stand-alone Advanced	Synchronization Basic	Synchronization Advanced
Emergency stop	•	•	•	•
High/Low frequency	•	•	•	•
High/Low voltage	•	•	•	•
Short-circuit	•	•	•	•
Incorrect phase sequence	•	•	•	•
Inverse power	•	•	•	•
Overload	•	•	•	•
Total hour counter	•	•	•	•
Kilowatt meter	•	•	•	•
Starts valid counters	•	•	•	•
Maintenance	•	•	•	•
USB	•	•	•	•
Software for PC	•	•	•	•
Alarm history	•	•	•	•
External start	•	•	•	•
Start inhibition	•	•	•	•
Mains failure start	•	•	•	•
Pre-heating engine control	•	•	•	•
Fuel transfer control	•	•	•	•
Engine temperature control	•	•	•	•
Programmable alarms	•	•	•	•
Genset start function in test mode	•	•	•	•
Programmable outputs	•	•	•	•
Multilingual	•	•	•	•
RS485		•	•	•
Modbus IP		•	•	•
J1939		•	•	•
Synchronization			•	•
Mains synchronization				•
Fuel level (%)	0	0	0	0
Low water level	0	0	0	0
GSM/GPRS modem	0	0	0	0
Remote screen	0	0	0	0
■ Standard ○ Optional				

● Standard ○ Optional

